

**Parts included:**

- 6ea. Button head screws
- 6ea. Tabs
- 6ea. Standoffs
- 3ea. Spacer Strips
- 1ea. Base
- 6ea. Lock nuts
- 1ea. Hex key tool

Additional tool required:

1 of the following: Adjustable wrench, 7/16" end wrench, or a 7/16" socket wrench.

**Assembling the Tray**

Using the illustrations above, note the order in which each of the 6 supports is assembled. Make sure the textured surface of the Tabs and Spacer Strips face toward the head of the screw. Also make sure the end of the Spacer Strips lines up with the Base end.

Tighten the screw until the assembly is snug then loosen the Lock nut until the tab can swing but still has friction against the Standoff.

**Installation into Tripod**

With the tripod setup ready for use, loosen the four knobs (two sides) one or two turns. Twist each tab so that it points in. Install the tray from the bottom up, so that the base rests against the bottom of the three tripod straps. Twist each tab so that they point away from the center and over the straps. Tighten the four tripod knobs.